








GRILLE EN OPTION
GRILL ON OPTION

TOLERANCE	30RQ 0140R-0160R		DATE 11-Aug-23	Feuille Sheet 1/6
±10	*	00DCG000421900		Indice D



COG AND LIFTING INFORMATION




COUPE / SECTION C-C
ECHELLE 21:64



X (mm)	Y (mm)	Z (mm)
815±50	1115±35	550±25







ELECTRICAL BOX INFORMATION





TOLERANCE	30RQ 0140R-0160R		DATE	Feuille
±10	*		11-Aug-23	Sheet
		00DCG000421900		3/6
				Indice
				D

Technical drawing of a square panel with two circular fans. The panel has a total width of 2002 and a total height of 2214. The fans are positioned vertically, each with a diameter of 860. The panel is divided into four quadrants by a horizontal line. The top and bottom quadrants are shaded with diagonal lines. The fans are labeled P1, P2, P3, and P4. The panel is also labeled with the number 13. The drawing includes dimensions for the panel, fans, and the distance between them.



30RQ UNITS (HP)	140 / 160 KW
X3	935
Y3	1041
Y4	1218
Z3	662



TOLERANCE	30RQ 0140R-0160R
± 10	*





DATE	F
11-Aug-23	T

00DCG000421900


euille
Sheet
4/6
ndice
D

XTRA FAN OPTION INFORMATION















OPTION POUR XTRA FAN*
OPTION FOR XTRA FAN*



DETAIL F
ECHELLE 1:10



TOLERANCE	30RQ 0140R-0160R	DATE	11-Aug-23	Feuille Sheet 5/6
±10	*	00DCG000421900	D	Indice

					00DCG000421900 D
SYMBOLS DESCRIPTIONS					
	ENGLISH	FRANCAIS	DEUTSCHE	ESPANOL	ITALIANO
	Unit water inlet and outlet	Entrée et sortie eau unité	Wasser eintritt und austritt	Entrada y salida agua unidade	Entrata e uscita acqua unita
	Water inlet and outlet OPT 049	Entrée et sortie eau OPT 049	Eintritt und austritt OPT 049	Entrada y salida agua OPT 049	Entrata e uscita acqua OPT 049
	N/A	N/A	N/A	N/A	N/A
	NA	NA	NA	NA	NA
	Safety relief valve LP	Soupape de sécurité BP	Verdampfer sichereitsventil LP	Valvula de seguridad LP	Valvola di sicurezza LP
	Safety relief valve HP	Soupape de sécurité HP	Verdampfer sichereitsventil HP	Valvula de seguridad HP	Valvola di sicurezza HP
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	NA	NA	NA	NA	NA
	Services clearances required	Espace nécessaire à la maintenance	Freiraum für wartung	Espacio necesario para servicio y mantenimiento	Spazio necessario per il servizio
	NA	NA	NA	NA	NA
	Electrical box	Coffret électrique	Schaltschrang	Caja electrica	Pannello elettrico
	Main disconnect switch	Interrupteur général	Haupttrennschalter	Interruptor de desconexion principal	Sezionatore general
	N/A	N/A	N/A	N/A	N/A
	Power supply unit recommend section wire (see IOM)	Raccordement électrique unité section recommandée (voir IOM)	Hauptelektrische anschluss querschnitt (IOM sehen)	Conexiones electricas unidade section recomendada (ver IOM)	Conezione elettrica de l'unità sezione racomandato(vedi IOM)
	Mass ditribution point	Point de répartition de masse	Massenverteilungspunkt	Punto de distribución masiva	Punto di distribuzione di massa
	Inlet water	Entrée eau	Wasser eintritt	Entrada agua	Entrata acqua
	Outlet water	Sortie eau	Wasser austritt	Salida agua	Uscita acqua
	Electrical supply entry	Entrée raccordement électrique	Strom Anschlüsse	Entrada cables electricos	Entrata cavi alimentazione
	NA	NA	NA	NA	NA
	Center of gravity	Centre de gravité	Maschinenschwerpunkt	Centro de gravedad	Centro di gravita
	Handling Rigging of the unit: the sizing of the rigging or lifting elements is the responsibility of the installer	Manutention de l'unité Le dimensionnement des éléments de manutention ou de levage sont sous la responsabilité du manutentionnaire	Anheben des geräts Der installateur ist für die dimensionierung der hebeelemente verantwortlich	Sostienento de la unidad Las dimensiones de los elementos de sostienento o levantamiento es responsabilidad de instalador	Sollevamento dell'apparechio La responsabilita del dimensionamento degli elementi di sistema di sollevamento e di pertinenza dell'installatore
				TOLERANCE ±10	30RQ 0140R-0160R * 00DCG000421900
					DATE 11-Aug-23 Indice D

Техника для климата

Доставляем оборудование по всей России от 3 дней транспортными компаниями. Реализуем проекты в десятках регионов — от Калининграда до Владивостока.

9600+

объектов и поставок

от 1 дня

отгрузка в транспортную компанию

Технические данные файла

Документ: Схема Carrier 30RQ 040R-160R, тепловые насосы воздух-вода: габаритный чертёж
00DCG000421900D, 10.2023

Идентификатор библиотеки: LIB-004163

Исходный файл: carrier-00dcg000421900d-10-2023-30rq-040r-160r-shema.pdf

SHA-256 оригинала: bd592f1952a93ea2f598770f9b9cb6667432f4c5a600665c70b96f9413de0de9

Постоянная ссылка: <https://iclim.ru/library/carrier-00dcg000421900d-10-2023-30rq-040r-160r-shema.pdf>

Копия сформирована: 04.10.2026 07:56 UTC