




42NC/ND UNIT SIZE – 1 RIGHT

STANDARD UNIT DIMENSIONS



42NC/ND UNIT FAMILY TYPES




Family Types
✕

Type name:




Search parameters

Parameter	Value	Formula	Lock
Visibility ⤴			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☐	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	


CABINET WITH FEET UNIT DIMENSIONS




CABINET WITHOUT FEET UNIT DIMENSIONS




LIFTING BRACKET DIMENSIONS




42NC/ND UNIT 4 PIPE – ½" GAZ




42NC/ND UNIT 2 PIPE – ½" GAZ




42NC/ND UNIT ELECTRICAL CONNECTION




ELECTRICAL CONNECTION




2 WAY VALVE WITH ON/OFF ACTUATOR 230V or 24V




4 WAY VALVE WITH ON/OFF ACTUATOR 230V or 24V






2 WAY AUTO-BALANCING VALVE WITH ACTUATOR



CONDENSATE PUMP FOR VERTICAL UNIT



CONDENSATE PUMP FOR HORIZONTAL UNIT




CONDENSATE PUMP


WITH CABINET - WITHOUT FEET




Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	




WITH CABINET - WITH FEET



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☒	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	





WITH CABINET – FEET WITH GRILL





Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☒	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	

CABINET WITH GRILL – WITHOUT FEET




Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☒	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

WITHOUT CABINET – WITHOUT FEET



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	"	
2 WAY VALVE	☐	"	
4 WAY VALVE	☐	"	
COIL 42NC/ND 2PIPE	☐	"	
COIL 42NC/ND 4PIPE	☒	"	
RECTANGULAR FLANGE	☐	"	
SUPPORT BASE FOR CONCEALED UNIT	☐	"	
VERTICAL CONDENSATE PUMP	☐	"	
CABINET WITH GRILL	☐	"	
CABINET WITHOUT GRILL	☐	"	
FEET WITH GRILL	☐	"	
FEET WITHOUT GRILL	☐	"	
HORIZONTAL CONDENSATE PUMP	☐	"	
NO CABINET	☒	"	
NO FEET	☒	"	
SERVICE AREA (Default)	☐	"	

WITHOUT CABINET – WITH FEET




Family Types


Type name:

Search parameters


Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	"	
2 WAY VALVE	☐	"	
4 WAY VALVE	☐	"	
COIL 42NC/ND 2PIPE	☐	"	
COIL 42NC/ND 4PIPE	☒	"	
RECTANGULAR FLANGE	☐	"	
SUPPORT BASE FOR CONCEALED UNIT	☐	"	
VERTICAL CONDENSATE PUMP	☐	"	
CABINET WITH GRILL	☐	"	
CABINET WITHOUT GRILL	☐	"	
FEET WITH GRILL	☐	"	
FEET WITHOUT GRILL	☒	"	
HORIZONTAL CONDENSATE PUMP	☐	"	
NO CABINET	☒	"	
NO FEET	☐	"	
SERVICE AREA (Default)	☐	"	





WITHOUT CABINET – BASE SUPPORT



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	"	
2 WAY VALVE	☐	"	
4 WAY VALVE	☐	"	
COIL 42NC/ND 2PIPE	☐	"	
COIL 42NC/ND 4PIPE	☒	"	
RECTANGULAR FLANGE	☐	"	
SUPPORT BASE FOR CONCEALED UNIT	☒	"	
VERTICAL CONDENSATE PUMP	☐	"	
CABINET WITH GRILL	☐	"	
CABINET WITHOUT GRILL	☐	"	
FEET WITH GRILL	☐	"	
FEET WITHOUT GRILL	☐	"	
HORIZONTAL CONDENSATE PUMP	☐	"	
NO CABINET	☒	"	
NO FEET	☒	"	
SERVICE AREA (Default)	☐	"	





WITHOUT FEET – RECTANGULAR FLANGE



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☒	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☒	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

SERVICE AREA



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☒	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☒	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☒	=	

A	B	C
150	210	100

Техника для климата

Доставляем оборудование по всей России от 3 дней транспортными компаниями. Реализуем проекты в десятках регионов — от Калининграда до Владивостока.

9600+

объектов и поставок

от 1 дня

отгрузка в транспортную компанию

Технические данные файла

Документ: Схема Carrier 42N, фанкойлы: BIM-модель Revit 42NC/42ND, типоразмер 1, правое подключение, 04.2021

Идентификатор библиотеки: LIB-004756

Исходный файл: carrier-revit-04-2021-42nc-nd-size-1-right-rev000-shema.pdf

SHA-256 оригинала: a8847502ff66d0f920a3b82f8688ddace0df9c2159f5f18e738ffdbe775bb2a1

Постоянная ссылка: <https://iclim.ru/library/carrier-revit-04-2021-42nc-nd-size-1-right-rev000-shema.pdf>

Копия сформирована: 03.10.2026 04:46 UTC