




42NC/ND UNIT SIZE – 6 RIGHT

STANDARD UNIT DIMENSIONS



42NC/ND UNIT FAMILY TYPES




Family Types
✕

Type name:
📁 📄 🗑️


Search parameters
🔍

Parameter	Value	Formula	Lock
Visibility ⬆			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☐	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	

CABINET WITH FEET UNIT DIMENSIONS




CABINET WITHOUT FEET UNIT DIMENSIONS




LIFTING BRACKET DIMENSIONS





42NC/ND UNIT 4 PIPE




42NC/ND UNIT 2 PIPE – $\frac{3}{4}$ " GAZ




42NC/ND UNIT ELECTRICAL CONNECTION




2 WAY VALVE WITH ON/OFF ACTUATOR 230V or 24V




4 WAY VALVE WITH ON/OFF ACTUATOR 230V or 24V




2 WAY AUTO-BALANCING VALVE WITH ACTUATOR



CONDENSATE PUMP FOR VERTICAL UNIT



CONDENSATE PUMP FOR HORIZONTAL UNIT



WITH CABINET - WITHOUT FEET




Family Types


Type name:

Search parameters

Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	




WITH CABINET - WITH FEET





Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☒	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	

WITH CABINET – FEET WITH GRILL





Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☒	=	
FEET WITH GRILL	☒	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☐	=	

CABINET WITH GRILL – WITHOUT FEET





Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☒	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☐	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

WITHOUT CABINET – WITHOUT FEET




Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☒	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

WITHOUT CABINET – WITH FEET





Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	"	
2 WAY VALVE	☐	"	
4 WAY VALVE	☐	"	
COIL 42NC/ND 2PIPE	☐	"	
COIL 42NC/ND 4PIPE	☒	"	
RECTANGULAR FLANGE	☐	"	
SUPPORT BASE FOR CONCEALED UNIT	☐	"	
VERTICAL CONDENSATE PUMP	☐	"	
CABINET WITH GRILL	☐	"	
CABINET WITHOUT GRILL	☐	"	
FEET WITH GRILL	☐	"	
FEET WITHOUT GRILL	☒	"	
HORIZONTAL CONDENSATE PUMP	☐	"	
NO CABINET	☒	"	
NO FEET	☐	"	
SERVICE AREA (Default)	☐	"	

WITHOUT CABINET – BASE SUPPORT





Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☒	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☒	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

WITHOUT FEET – RECTANGULAR FLANGE



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☒	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☐	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☒	=	
NO FEET	☒	=	
SERVICE AREA (Default)	☐	=	

SERVICE AREA



Family Types			
Type name:			
Search parameters			
Parameter	Value	Formula	Lock
Visibility			
2 WAY AUTO-BALANCING VALVE	☐	=	
2 WAY VALVE	☐	=	
4 WAY VALVE	☐	=	
COIL 42NC/ND 2PIPE	☐	=	
COIL 42NC/ND 4PIPE	☒	=	
RECTANGULAR FLANGE	☐	=	
SUPPORT BASE FOR CONCEALED UNIT	☐	=	
VERTICAL CONDENSATE PUMP	☐	=	
CABINET WITH GRILL	☐	=	
CABINET WITHOUT GRILL	☐	=	
FEET WITH GRILL	☐	=	
FEET WITHOUT GRILL	☒	=	
HORIZONTAL CONDENSATE PUMP	☐	=	
NO CABINET	☒	=	
NO FEET	☐	=	
SERVICE AREA (Default)	☒	=	

A	B	C
150	210	100

Техника для климата

Доставляем оборудование по всей России от 3 дней транспортными компаниями. Реализуем проекты в десятках регионов — от Калининграда до Владивостока.

9600+

объектов и поставок

от 1 дня

отгрузка в транспортную компанию

Технические данные файла

Документ: Схема Carrier 42N, фанкойлы: BIM-модель Revit 42NC/42ND, типоразмер 6, правое подключение, 04.2021

Идентификатор библиотеки: LIB-004758

Исходный файл: carrier-revit-04-2021-42nc-nd-size-6-right-rev000-shema.pdf

SHA-256 оригинала: ff59236b15b4375bb78d4aa983404e924ba7341062615aa2d1a18e2f5e30e46e

Постоянная ссылка: <https://iclim.ru/library/carrier-revit-04-2021-42nc-nd-size-6-right-rev000-shema.pdf>

Копия сформирована: 03.10.2026 04:46 UTC